

permanently pause updates windows with powershell

 [google.com/search](https://www.google.com/search)

1. **Open PowerShell as an Administrator:** Right-click the Start button and select **Windows PowerShell (Admin)** or **Command Prompt (Admin)**.
2. **Stop the service and disable startup** with the following commands, pressing Enter after each:
powershell

```
net stop wuauserv  
sc config wuauserv start=disabled
```

Alternatively, you can use the **Set-Service** cmdlet in PowerShell:
powershell

```
Stop-Service wuauserv  
Set-Service wuauserv -StartupType Disabled
```

To re-enable updates later, use:

```
sc config wuauserv start=auto  
net start wuauserv
```